


FAST SC/ST (Universal)

NEW
Product


Field Assembly with Simple Technique



Fast SC/ST connector incorporates a new disposable wedge tool system, eliminating the need for expensive specialised tooling.


A Proven “Mechanical Splice” technique in each connector ensures reliable and quick connection wherever you are!

“Universal” the FAST SC/ST connectors, can now be terminated to both 0.25 & 0.9mm Diameter fibre.



Assemble in 5 easy steps

1. Prepare Fibre
2. Push wedges to insert Fibre
3. Fibre mates with pre-installed Fibre
4. Release wedges to clamp
5. Assemble connector



 **Fujikura**
EUROPE LTD

[e] fibre_optics@fujikura.co.uk [w] www.fujikura.co.uk

